

2. Self-Inspection

Inspection Matters before Usage

1. Is the power cord properly plugged into the outlet?
2. Are the connectors (Remote Control and external Projectors to the Main Mat) properly plugged and fastened?
3. Is the FND display of the remote control on?
4. Did you check whether or not the projectors are set to the ideal temperature of 45~55°C?
5. Are there any damages to the projector covers?
6. Did you check to see if there are any damages on the project cover?

Self-Inspection after use

1. Is the FND display of the remote control turned off?
2. Are the connectors (Remote Control and external Projectors to the Main Mat) properly plugged and fastened?
3. Did you check whether the power switch is turned off?
4. Did you check whether the power cord is unplugged?